



Multimedia Terminals.

Top class patient entertainment.

HEALTH CARE

www.schrack-seconet.com

SCHRACK
S E C O N E T

MultiMEDIA

- Comprehensive range of entertainment
- Simple to operate
- Pin sharp picture quality
- Perfect design



Patient entertainment gaining importance.



Quality entertainment in hospital.

Changes in the healthcare system can not be overlooked: hospitals are becoming centres for healthcare and are in direct competition with one another. The boundaries between hotel-class comfort and healthcare services are becoming increasingly blurred. Entertainment is becoming an important element of the recuperation process: it increases patients' state of well-being, takes their mind off things and informs them – while on the other hand also giving care staff time that can be used for efficient patient care.

Technology for people in exceptional circumstances.

The latest patient bed technology also needs to be simple and intuitive to operate even in extreme situations, must function flawlessly and also be easy to look after. Patients are often older people in exceptional situations, who are even more grateful than in their daily life for things being simplified and clear – and prefer all the more to use communications facilities that are constructed accordingly.



Top quality to handle everyday demands.

Schrack Seconet's multimedia terminals are manufactured in such a way in terms of the technology and the choice of materials used, that they are able to withstand the stress and strain of a hospital environment for a long time. There are a wide range of options, they are simple to operate and their design is impressive.

A tailored programme for everyone.

The modern terminal for every hospital bed allows greater variety for hospital stays and allows people to be given space. Nobody is disturbed – while everyone is connected with the outside world in a manner that best mirrors their personal lifestyle and their requirements.



reddot design award
winner 2011



MultiMEDIA

- Different types of functions
- Various screen sizes
- Flexible installation
- Top quality

Adaptable, versatile, and reliable.



Comprehensive use of modern media.

Our terminals are oriented in their ability to perform towards the developments in home entertainment and therefore use all the options available from modern communications technology. Depending on the version of the terminal chosen, they are equipped for analogue reception, DVB-T and DVB-C and even IP TV, and therefore also permit access to the Internet.

Ideal screen sizes.

It is all dependent on distance: Being at an unsuitable distance from the screen and poor picture quality can cause headaches. Opticians therefore recommend viewing from a distance that is approximately five times the diagonal screen size. Schrack Seconet's Multimedia Terminals are designed to provide the optimal solution for the most popular viewing distances.

The best view – even in difficult conditions.

In order to provide patients with a relaxing television viewing experience, even where there are difficult space issues to overcome, while not disrupting patient care, there are several possible ways of fitting the terminals: The terminals can be either fitted on flexible wall-mounted arms or mounted on bedside cabinets.

External devices like DVD players, iPods, gaming consoles etc. can be connected.

Even the smallest terminal impresses with its comprehensive range of functions: Analogue and digital television and radio reception, AV and USB interfaces, integrated stereo loudspeakers and a headphone connection are included as a matter of course. The larger models impress with extended options for connection, touch screen operation and various menu languages.

Operation on demand.

Operation of the devices is self-explanatory and depending on the device model is via a membrane keypad and/or a touch screen. Emphasis always remains on simple operability.



reddot design award
honourable mention 2010

MultiMEDIA

- Can be used flexibly
- Future-proof technology
- Cost-efficient to get started
- Robust and reliable



Equal to any challenge.



Flat panel monitor	MediTec 8.5"	MediTec 10"	MediStream 10"	MediNet 15"
Diagonal screen size	21.6 cm, 8.5"	25.6 cm, 10.1"	25.6 cm, 10.1"	39.6 cm, 15"
Picture format	16:9	16:9	16:9	16:9
Resolution	480x234xRGB (WQVGA)	1024x600xRGB (WSVGA)	1024x600xRGB (WSVGA)	1366x768xRGB (WXGA)
Dimensions WxHxD (in mm)	247x202x30	287x226x30	287x226x30	395x310x56
Weight	0.9 kg	1.0 kg	1.0 kg	3.9 kg *1)
Operating voltage	15 V DC	15 V DC	15 V DC	15 V DC
On-screen display	●	●	●	●
TV over IP	—	—	●	●
TV over DVB-T	●	●	●*2)	●
TV over DVB-C	●	●	—	●
Analogue TV	●	●	—	●
Internet over IP	—	—	●	●
Radio over IP	—	—	●	●
Radio over DVB-T	●	●	●*2)	●
Radio over DVB-C	●	●	—	●
Radio over analogue	●	●	—	●
Integrated loudspeaker	●	●	●	●
Headphone connection	●	●	●	●
Membrane keypad	●	●	●	●
Touch screen	—	—	●	●
AV connection	●	●	●	●*3)
USB connection	①*4)	①*4)	①	②
Sleep timer	●	●	●	●
Channel overview	●	●	●*5)	●*5)
Teletext	●	●	—	—
VOD	—	—	●*6)	●*6)
Bedside cabinet mounting arm NT GFK	●	●	●	—
Bedside cabinet mounting arm NT E/GFK	●	●	●	●
Wall-mounted arm type O 500	●	●	●	●
Ceiling-mounted arm	●	●	●	●

*1) dependent on version, *2) currently in development, *3) not in Full IP, *4) only for loading devices, *5) Direct touch screen selection, *6) with additional centralised modules



SCHRACK SECONET AG

Headquarter Austria: A-1120 Vienna, Eibesbrunnergasse 18 • Tel.: +43-1-81157-0 • office@schrack-seconet.com • www.schrack-seconet.com

Branch offices Austria:

A-6850 Dornbirn, Sebastianstraße 13a • Tel.: +43-5572-51199-0
A-8055 Graz, Neuseiersberger Straße 157 • Tel.: +43-316-407676-0
A-6020 Innsbruck, Dr.-Franz-Werner-Straße 36 • Tel.: +43-512-365366-0
A-9020 Klagenfurt, Feldkirchner Straße 138 • Tel.: +43-463-429362-0
A-4060 Leonding-Hart, Kornstraße 16 • Tel.: +43-732-677900-0
A-5020 Salzburg, Vogelweiderstraße 44a • Tel.: +43-662-887122-0

Czech Rep. • CZ-100 00 Prague 10, V Úžlabině 1490/70 • Tel.: +420-2-74782284
Hungary • HU-1119 Budapest, Fehérvári út 89-95 • Tel.: +36-1-4644300
India • IN-122002 Gurgaon, DLF Golf Course Road, Sector-54 • Tel.: +91-124-4141501
Poland • PL-02-672 Warsaw, ul. Domaniewska 44a, bud. Platinum V • Tel.: +48-22-33 00 620
Romania • RO-021723 Bucharest, Sos.Iancului nr. 6A, Sector 2 • Tel.: +40-372 756 316
Russia • RU-129626 Moscow, Ul. Staroalexejevskaja 5 • Tel.: +7-495-510 50 15
Slovakia • SK-83527 Bratislava–Rača, Mudrochova 2 • Tel.: +421-2-44635595
Sweden • SE-145 84 Norsborg, Botvid Business Center • Tel.: +46-8-680 18 60
Turkey • TR-34722 Kadıköy–İstanbul, Kasap İsmail Sk. 5/5 • Tel.: +90-216-345 51 99

Sales partners in:

HEALTH CARE

www.schrack-seconet.com

SCHRACK
S E C O N E T